

Digital Tyre Depth Gauge

Art. Nr: PT8116

Specifications

1. Range: 0 - 25.4mm
2. Resolution: 0.01mm
3. Working temp.: 0 - 40°C
4. Battery: SR44/LR44, 1.5V

Important

1. Keep the gauge clear
2. No water/oil on bar (1)
3. Remove battery when not in used for long periods
4. Display flashes when battery power is low
5. Accidental display failure: take out battery for 30 seconds

How To Use

1. Insert battery in (2), + pole upwards
2. Switch ON (4)
3. Put base (5) on flat surface and press bar (1) downward
4. Set ZERO (3)
5. Put gauge on tyre, hold stable and press bar tip (6) into tyre profile
6. Read profile depth value directly
7. Switch OFF (4) or continue

